

11String cable shorting method

1. Preparation. The cable must be soldered to the battery pack first, and then plugged into the protection board after checking it correctly. Do not plug the cables into the protection board and then solder them to the battery pack one by one
2. When wiring, connect B negative first, then connect the cable, and finally connect C negative to the negative pole of the charger and the load. The battery is always connected to the charger and battery
3. Starting from the 9th series of cables on the board, connect the 9th to 19th series to the positive pole of the 9th battery of the battery pack, the 20th series of cables to the positive pole of the 10th series of batteries, and the 21st series of cables to the battery Positive pole (that is, the positive pole of the 11th string of batteries)

C negative to charge and discharge negative

